



**Horizontal Units**

**HP012H  
 & UP TO  
 HP018H**




**'R' CONFIGURATION**

**HP024H  
 & UP TO  
 HPX060H**




**'R' CONFIGURATION**

**HPX072H  
 & HPX144H**



**'L' CONFIGURATION**


**HPX090H  
 AND UP TO  
 HPX120H**




**'L' CONFIGURATION**

**Vertical Units**

**HPX024V -  
 HPX072V**



**'LF' CONFIGURATION  
 HPX090V - HPX120V**



**'LF' CONFIGURATION**